


medlab

# Five Lead ECG OEM board

# EG05000

Technical Manual



Copyright © Medlab 2004 - 2009


Version 1.04

Medlab GmbH  
Erzbergerstrasse 115  
76133 Karlsruhe  
Germany  
Tel ++49 (0) 721 62512 0  
Fax ++49 (0) 721 62512 66  
oemsales@medlab-gmbh.de  
www.medlab-gmbh.de

# Table of content

<b>Mechanical Dimensions</b>	<b>4</b>
<b>Overview</b>	<b>4</b>
<b>Description of the Module Areas</b>	<b>5</b>
<b>Physical Units of Transmitted Data</b>	<b>5</b>
<b>Specifications</b>	<b>6</b>
<b>Connector Assignment</b>	<b>7</b>
<b>Compliance with IEC60601-2-27</b>	<b>8</b>
<b>Serial Transmission</b>	<b>10</b>
<b>Software Protocol Description</b>	
<b>Introduction</b>	<b>11</b>
<b>Packet Description</b>	<b>13</b>
<b>Commands</b>	<b>15</b>
<b>PC Test Program</b>	<b>17</b>
<b>Regulatory Considerations</b>	<b>18</b>
<b>Revisions of this document</b>	<b>18</b>

## Mechanical dimensions of the module



mechanical drawing, top view of the module (1:1)

## Overview

The scope of this document is the description and specification of Medlab's five lead ECG board EG05000. It should help anybody who is familiar with programming and basic electronics both to select the proper hardware and software version for his application as well as to help him integrate the board into his own electronic system.

The EG05000 measures maximum seven channels of ECG by using a five lead cable. The isolated patient ground must not be connected to the mains ground. The EG05000 has the full patient isolation on the board, that means that the input voltage of 5 volts has no galvanic contact to the patient. Furthermore, the module is defibrillation protected.

The isolation gap can be easily seen on the board: it is the area that is bridged only by the transformer 76250 and the couplers ADUM2402.


No connections to anything except the patient cable must be made on the patient cable input side of the module (see drawing on the next page).

When using a five lead cable, the module can output the following channels synchronously: I, II, III, aVR, aVL, aVF, C.

When using a four lead cable, the module can output the following channels synchronously: I, II, III, aVR, aVL, aVF.

When using a three lead cable, the module can output the following channels: I or II or III.

## Description of the Module Areas and Connectors



description of connectors and areas of the module (1:1)

## Physical Units of Transmitted Data

Scaling of ECGs is done traditionally in the unit "cm/mV" for the Y-axis and in "mm/sec" for the X-axis.

Respiration rate is transmitted in „rpm“, e.g. respirations per minute.

Pulse rate is transmitted in „bpm“, e.g. beats per minute.

Transmission speed for the wave is indicated in Hz (sec<sup>-1</sup>).

ECG amplitudes are normally indicated in „cm/mV“. Since this is directly depending on the resolution of the screen the user is working on, the transmitted samples are not scaled, but fall into the range of 0-0xF7 (8 Bit samples, 0xF8 to 0xFF reserved for commands). It is within the responsibility of the user to scale the transmitted samples so that the waves displayed onto his screen fit to the usual scales used in medicine, 0.5, 1, 2 and 4 cm/mV. The amplification of the module in the different amplification stages is:

Stage 1	Stage 2	Stage 3	Stage 4
1mV = 32	1mV = 64	1mV = 128	1mV = 256

Normal values for the trace speed are 12.5 mm/sec, 25 mm/sec and 50 mm/sec.

## Technical data (Specifications):

Mechanical data:	88mm x 53mm see page 4 for board drawing 4 layer PCB, thickness 1.5 mm
Maximum height:	12 mm
With respiration option:	25mm
Attachment:	four M2.5 screws in the corners of the PCB
Weight :	32 g
Operating voltage:	5 Volt, +- 10% , 50 mA
Power consumption:	250mW while measuring
Input:	Defibrillation protected
Isolation:	4000Volts RMS
Amplification:	Four levels, user selectable
Data transmission:	Four frequencies, user selectable
Filtering:	50 Hz or 60 Hz notch filter included
Amplifier frequency range:	0.05 to 70 Hz.
Pulse detection:	30 .. 250 bpm +- 1%, +- 1 Digit, 8 beat average
Respiration detection:	5 .. 99 rpm +-3%, +- 1 Digit, 8 samples average (option)
Output:	Asynchronous serial output with CMOS levels (0...5V) Hardware pulse trigger output, CMOS levels (0...5V) Both outputs fully isolated from patient
Protocol:	Standard bidirectional serial protocol, see description on following pages
Connector:	Connectors compatible to Medlab EG01001 three channel OEM board

# Connectors:

(see attached drawing for location)

## Header for host connection:


JP1:	1	Ground
	2	Ground
	3	Txd (RS232 level +/- 5Volt)
	4	Txd (TTL level)
	5	Rxd (RS232 level +/- 5Volt)
	6	Rxd (TTL level)
	7	Not connected
	8	Not connected
	9	Not connected
	10	Not connected
	11	Pulse Trigger output (Version 41751)
	12	Pulse Trigger output (Version 41752)
	13	Shutdown (Version 41751)
	14	Shutdown (Version 41752) VCC level on this pin powers down module
	15	VCC input
	16	VCC input

**Note:**

Since hardware revision 41751 and 41752 had pins 11-12 and 13-14 exchanged, version 41753 now has the respective signals on both pins, e.g. Pulse Trigger is on pin 11 **and** pin 12, Shutdown is on pin 13 **and** 14. The pulse trigger is a high active, rectangular signal with a pulse width of 33ms. Delay to the R wave can be adjusted by a command.

## Header for patient cable connection

SV1:	1	C-IN
	2	SHIELD
	3	LL-IN
	4	RA-IN
	5	LA-IN
	6	SHIELD
	7	RL-IN



ECG cable connection

## Technical description for TRF IEC 60601-2-27:

When preparing a test report form (TRF) for proof of compliance of the users medical product to IEC60601-2-27:2005, the following remarks / technical data will be helpful or needed:

Input Impedance:	> 10 MOhm
Common mode rejection ratio:	> 90 dB at 50 Hz or 60 Hz
Input Dynamic Range:	$\pm 5$ mV AC, $\pm 300$ mV DC
Defibrillator Discharge Recovery:	<10 sec per IEC 601-2-27 <10 sec per AAMI EC13-1992
Leads-off sensing current:	Applied currents less than 150 nA

### The following information references particular sections of IEC 601-2-27

#### Respiration (optional) Section 6.8.2.bb.1

Applied currents less than 80  $\mu$ A @ 90kHz square

#### Tall T-wave rejection. Section 6.8.2.bb.2)

T-wave of 1.2 mV amplitude will not affect heart rate determination.

#### Heart rate averaging. Section 6.8.2.bb.3)

**TBD**

#### Response to irregular rhythm. Section 6.8.2.bb.4)

A1) Ventricular bigeminy: the EG05000 counts both large and small QRS complexes to display a rate of 80 bpm.

A2) Slow alternating ventricular bigeminy: the EG05000 counts both large and small QRS complexes to display a rate of 60 bpm.

A3) Rapid alternating ventricular bigeminy: the EG05000 counts all QRS complexes to display a rate of 120 bpm.

A4) Bi-directional systoles: the EG05000 counts all QRS complexes to display a rate of 90 bpm.

#### Heart rate meter response time. Section 6.8.2.bb.5)

a) Change from 80 to 120 BPM: 4 sec

b) Change from 80 to 40 BPM: 7 sec

Time to alarm for tachycardia. Section 6.8.2.bb.6)

Waveform B1:	Amplitude	Time to alarm
	0,5 mV	1 sec
	1 mV	1 sec
Waveform B2	2 mV	1 sec
	Amplitude	time to alarm
	1 mV	1 sec
	2 mV	1 sec
	4 mV	1 sec

#### Pacemaker pulse display capability (See IEC 601-2-27 clause 50.102.12)

The EG05000 is capable of displaying the ECG signal in the presence of pacemaker pulses with amplitudes of  $\pm 2$  mV to  $\pm 700$  mV and durations of 0.1 ms to 2.0 ms. An indication for the pacemaker pulse is provided.

**Pacemaker pulse rejection (See IEC 601-2-27 clause 50.102.13)****Without over/undershoot:**

- a) For single (ventricular-only) pacemaker pulses alone, with 0.1 and 2.0 ms pulse-widths and  $\pm 2$  mV and  $\pm 700$  mV pulse-amplitudes, the EG05000 correctly displays heart rate as zero bpm (Asystole).
- b) For single (ventricular-only) pacemaker pulses with normally paced QRS-T, with 0.1 and 2.0 ms pulse-widths and  $\pm 2$  mV and  $\pm 700$  mV pulse-amplitudes, the EG05000 correctly displays heart rate of the QRS-T rhythm (60 bpm for the specified test waveform).
- c) For single (ventricular-only) pacemaker pulses with ineffectively paced QRS pattern, with 0.1 and 2.0 ms pulse-widths and  $\pm 2$  mV and  $\pm 700$  mV pulse-amplitudes, the EG05000 correctly displays heart rate of the underlying QRS-T rhythm (30 bpm).
- d) For atrial/ventricular pacemaker pulses alone, with 0.1 and 2.0 ms pulse-widths and  $\pm 2$  mV and  $\pm 700$  mV pulse-amplitudes, the EG05000 correctly displays heart rate of zero bpm (Asystole).
- e) For atrial/ventricular pacemaker pulses with normally paced QRS-T, with 0.1 and 2.0 ms pulse-widths and  $\pm 2$  mV and  $\pm 700$  mV pulse-amplitudes, the EG05000 correctly displays heart rate of the QRS-T rhythm (60 bpm).
- f) For atrial/ventricular pacemaker pulses with ineffectively paced QRS pattern, with 0.1 and 2.0 ms pulse-widths and  $\pm 2$  mV and  $\pm 700$  mV pulse-amplitudes, the EG05000 correctly displays heart rate of the underlying QRS-T rhythm (30 bpm).

**With over/undershoot:**

- a) For single (ventricular-only) pacemaker pulses alone, with 0.1 and 2.0 ms pulse-widths and  $\pm 2$  mV and  $\pm 700$  mV pulse-amplitudes, the EG05000 correctly displays heart rate of zero bpm (Asystole).
- b) For single (ventricular-only) pacemaker pulses with normally paced QRS-T, with 0.1 and 2.0 ms pulse-widths and  $\pm 2$  mV and  $\pm 700$  mV pulse-amplitudes, the EG05000 correctly displays heart rate of the QRS-T rhythm (60 bpm).
- c) For single (ventricular-only) pacemaker pulses with ineffectively paced QRS pattern, with 0.1 and 2.0 ms pulse-widths and  $\pm 2$  mV and  $\pm 700$  mV pulse-amplitudes, the EG05000 correctly displays heart rate of the underlying QRS-T rhythm (30 bpm).
- d) For atrial/ventricular pacemaker pulses alone, with 0.1 and 2.0 ms pulse-widths and  $\pm 2$  mV and  $\pm 700$  mV pulse-amplitudes, the EG05000 correctly displays heart rate of zero bpm (Asystole).

## Serial Transmission

Then normal connection to the board is done via serial, asynchronous communication at 115200 baud, 8 data bits, even parity bit and one stop bit. Both CMOS and RS232 (+/- 5 Volt level) voltage levels are available.

This protocol is block oriented. Each block also has a checksum in the transmitted data.

Optionally, an EG01001 compatible protocol version is available.

This protocol is compatible with the EG01001 three channel ECG board. Not all features of the EG05000 are available in this mode, since the three channel ECG supports one ECG channel transmission at one time only.

The RS232 voltage levels are helpful during evaluation of the board, which can be done using an ordinary PC and a special software. The connection in the customer's final system could be done through 0V/5V levels, which saves parts on the customer's side of the data stream.

Connector JP1 is compatible with the interface connector on Medlab's EG01001 three channel ECG OEM board. Therefore, test cables that had been built for this board can be used also for the EG05000 board.

The EG05000 sends data and receives commands. Commands are one byte characters, some of them have an additional parameter, others just toggle an internal switch in the EG05000 module.

The neutral line of the ECG always lies around 128, since the module transmits unsigned data.

For details, please see the protocol description on the following pages.

**The protocol described is the native EG05000 protocol.**

For the EG01001 protocol version that is available as an option, please see the EG01001 manual.

## Serial Transmission Protocol

The board transmits up to 8 graphical waveforms synchronously, a pulse value, a respiration value if the optional respiration board is fitted to the base ECG board and several status bytes. Transmission is done in blocks. The integrity of the blocks is secured by:

- 1) an even parity bit in each transmitted byte.
- 2) a checksum for each block

Even parity in this case means that the sum of all bits in one byte, including the parity bit, is „0“.

The module can receive commands over its serial interface. For example, the user can select transmission speed of the wave block, set the amplification of the ECG amplifiers and select which channels should be transmitted by the board. The transmitted channels that are available with a five lead cable are:

- 1) I, Einthoven Lead
- 2) II, Einthoven Lead
- 3) III, Einthoven Lead
- 4) aVR, Goldberger Lead
- 5) aVL, Goldberger Lead
- 6) aVF, Goldberger Lead
- 7) C1, one Wilson lead that can be placed freely on the chest of the patient
- 8) Respiration curve

To reduce overhead for the waveform transmission, the wave block uses another checksum algorithm as the status and value blocks do.

The EG05000 works with a three lead-, a four lead- or a five lead cable. Only parts of the maximum number of channels can be measured if not all five electrodes are connected (see page 7).

The board contains a lead-off detection that gives information about each single non-connected electrode.

It is not possible for the module to automatically detect which cable is connected, since the situation is the same whether, for example, a three lead cable - or - a five lead cable with two non-attached leads is used.

It is recommended for the user to use a connection system with coded cables (shorted, unused pins in the connector for example) to make the host system aware of which cable style currently is connected to the EG05000 and to ignore lead-off messages that do not exist for the respective cabling system. The simpler solution is to have the end-user select which cable is connected in a menu entry in the monitor.

Channels that are requested by the host but cannot be measured because of no electrode contact or the respective lead missing in the cable are transmitted as "0x80", neutral line.

Transmission is done in blocks. The basic interface parameters are:

**115200 baud, 1 start bit, 8 data bits, even parity bit and one stop bit.**

The first block transmitted will be a status block.

Using a high baud rate is necessary because in case all channels are selected, much more data needs to be transmitted per second.

The default settings after power up are:

100 wave blocks per second, I,II,III activated, 1cm /mV amplification, monitoring bandwidth, 50Hz filter active. The host can adjust this to his needs by sending commands to the module.

To keep traffic on the serial line as low as possible, the following protocol has been implemented. The reasons for choosing that protocol where as following:

Especially the wave blocks are to be transmitted quite often (up to 300 times per second) and contain sometimes only one channel information. For this single channel, one needs at least: a block header, a counter, a checksum and the wave sample. To reduce overhead, the number of waves have been packed into one byte together with the checksum. The checksum for the wave packet can only be 4 bits long, because four bits are needed for the wave counter. The status and the value blocks use 7 bit checksums. There is still enough security, because each byte has its own parity bit.

### **Transmitted blocks:**

1. There are three types of regular data packets, **waveform blocks**, **value blocks** and **status blocks**. Beginning of a packet is indicated by the marker 0xF8 (wave), 0xF9 and 0xFA (values) and 0xFC (status). Every other transmitted byte has a value of less than 0xF8. Therefore, synchronisation is easy.
2. Waveform blocks are transmitted 50, 100, 150 or 300 times per second, as defined by the last „Speed“ command. Initial value is 100 / sec.
3. Status blocks are transmitted once per second.
4. Value blocks are transmitted at each detected pulse (0xFA marker, can be used for a pulse „beep“) and at each detected respiration (0xF9 marker).
5. The data protocol is self synchronizing, e.g. one cannot loose synchronisation when some bytes are lost during transmission. Only one package is lost in that case.
6. There is one special package: after receiving the command „I“ („identify“), the board sends a string that contains the board's name, hardware version info („H0“), software version info („S01“). This string is in ASCII format, and is zero terminated. The identification block starts with marker 0xFD, to ease decoding.

Example for answer to identify command:

```
<0xFD>"EG05000H0S01"<0x00>
```

On the next page, the structure of the blocks are described.

A waveform block contains between three and 10 bytes:

	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1 <b>Sync</b>	1	1	1	1	1	0	0	0
Byte 2 <b>Ctr/Chk</b>	Bit 3 Ctr	Bit 2 Ctr	Bit 1 Ctr	Bit 0 Ctr	Bit3 Chksum	Bit2 Chksum	Bit1 Chksum	Bit0 Chksum
Byte 3 <b>Wave 1</b>	Bit 7 Wave 1	Bit 6 Wave 1	Bit 5 Wave 1	Bit 4 Wave 1	Bit3 Wave 1	Bit2 Wave 1	Bit1 Wave 1	Bit0 Wave 1
Byte 4 <b>Wave 2</b>	Bit 7 Wave 2	Bit 6 Wave 2	Bit 5 Wave 2	Bit 4 Wave 2	Bit3 Wave 2	Bit2 Wave 2	Bit1 Wave 2	Bit0 Wave 2
Byte 5 <b>Wave 3</b>	Bit 7 Wave 3	Bit 6 Wave 3	Bit 5 Wave 3	Bit 4 Wave 3	Bit3 Wave 3	Bit2 Wave 3	Bit1 Wave 3	Bit0 Wave 3
Byte 6 <b>Wave 4</b>	Bit 7 Wave 4	Bit 6 Wave 4	Bit 5 Wave 4	Bit 4 Wave 4	Bit3 Wave 4	Bit2 Wave 4	Bit1 Wave 4	Bit0 Wave 4
.....								

2+Ctr bytes are transmitted in this block. Ctr is the number of wave samples in the block.

The checksum is the sum of all bytes in the block, including the sync character, modulo 16.

The wave samples are limited to a number of 0xF7, so no mix-up with sync bytes can occur.

The channels are not mapped one to one to the byte position in the block, since the user can freely enable/disable all channels independantly.

**The transmission sequence is always: I,II,III,aVR,aVL,aVF,C1,Respiration**

Example 1:the host requests „I“,„aVF“ and „C1“ to be transmitted. Wave 1 will be „I“, Wave 2 will be „aVF“ and Wave 3 will be „C1“ , the block being 5 bytes long.

Example 2, the host requests „C1“ and respiration waveform to be transmitted. Wave 1 will be „C1“, Wave 2 will be respiration waveform, the block being 4 bytes long.

A value block contains three bytes:

	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1 <b>Sync</b>	1	1	1	1	1	0	Bit 1 Type	Bit 0 Type
Byte 2 <b>Chksum</b>	0	Bit 6 Chksum	Bit 5 Chksum	Bit 4 Chksum	Bit 3 Chksum	Bit 2 Chksum	Bit 1 Chksum	Bit 0 Chksum
Byte 3 <b>Value</b>	Bit 7 Value	Bit 6 Value	Bit 5 Value	Bit 4 Value	Bit 3 Value	Bit 2 Value	Bit 1 Value	Bit 0 Value

3 bytes are transmitted in this block.

Type == 00 -> not used

Type == 10 -> respiration value

Type == 01 -> pulse value

Type == 11 -> not used, but reserved for future extensions

The checksum is the sum of all bytes in the block, including the sync character, modulo 128.

The values are limited to a number of 0xF7, so no mix-up with sync bytes can occur.

A Status block contains five bytes:

	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 1 <b>Sync</b>	1	1	1	1	1	1	0	0
Byte 2 <b>Checksum</b>	0	Bit 6 Checksum	Bit5 Checksum	Bit 4 Checksum	Bit3 Checksum	Bit2 Checksum	Bit1 Checksum	Bit0 Checksum
Byte 3 <b>Electrode</b>	0	Respwav	X	Chest	RA	LA	RL	LL
Byte 4 <b>Channels</b>	0	C1	aVF	aVL	aVR	III	II	I
Byte 5 <b>EKGStat</b>	X	Bit 1 Filter 2	Bit 0 Filter 2	EMG Filter1	Bit 1 Amp	Bit 0 Amp	Bit 1 Speed	Bit 0 Speed
Byte 6 <b>Status</b>	0	X	X	X	Bit 3 Status	Bit 2 Status	Bit 1 Status	Bit 0 Status

5 bytes are transmitted in this block. „X“ means the bit is unused and undefined

The checksum is the sum of all bytes in the block, including the sync character, modulo 128.

Electrodes, Byte 3: a „1“ in the respective bit position 0 .. 4 means this electrode is connected

Respwav: „1“ respiratory waveform sample is transmitted  
 „0“ respiratory waveform sample is not transmitted

Channels, Byte 4: a „1“ in the respective bit position 0 .. 6 means this wave is transmitted

EKG Status, Byte 5: Speed: „00“ 50 wave blocks per second  
 „01“ 100 wave blocks per second  
 „10“ 150 wave blocks per second  
 „11“ 300 wave blocks per second  
 Amp: „00“ Amplification stage 1 (lowest)  
 „01“ Amplification stage 2  
 „10“ Amplification stage 3  
 „11“ Amplification stage 4 (highest)

Filter1:	„0“	EMG filter off
	„1“	EMG filter on
Filter2:	„00“	50/60 Hz filter off
	„01“	50 Hz filter on
	„10“	60 Hz filter on
Status, Byte 6:	0	0000 Normal operation
	1	0001 Normal operation, pacemaker detected
	4	0100 Initializing
	5	0101 Searching for electrodes
	8	1000 Simulated output
	10	1010 Selftest error
	Rest:	Not used, but reserved

„Selftest error“ (10) errors are fatal. The module will never go into measuring state.

Status message 8 will be transmitted as long as simulated data is transmitted.

## Commands accepted by the module:

All commands have a one or two byte structure. They are also sent to the module with 115200 baud. The commands are sent in ASCII format.

Basic Bandwidth of ECG amplifier (Diagnostic or Monitoring mode):

- „F“ Parameter: "0" or "1"
- „0“ bandwidth of the amplifier DC-80 Hz Diagnostic mode (bear in mind mains filter setting)
- „1“ bandwidth of the amplifier 0.67-40 Hz Monitoring mode (reset value)

Transmission frequency of the waveform packet:

- „S“ Parameter: "0", "1", "2" or "7" (0x53 0x31 for example for „S1“)
- „0“ send waveform packets 50 times per second
- „1“ send waveform packets 100 times per second (reset value)
- „2“ send waveform packets 150 times per second
- „7“ send waveform packets 300 times per second

Amplification of the waveforms

- „A“ Parameter: "0", "1", "2" or "3" (0x41 0x31 for example for „A1“)
- „0“ Amplification stage 1 (lowest amplification, should be scaled to 0.5 cm/mV)
- „1“ Amplification stage 2
- „2“ Amplification stage 3
- „3“ Amplification stage 4 (highest amplification, should be scaled to 4 cm/mV)

Each amplification stage has **double the sensitivity** of the previous stage

Channel selection (1-8 wave channels can be selected)

„C“ Parameter: 1 byte. Each bit in the parameter byte set to „1“ stands for a transmitted wave, a „0“ means that wave is not transmitted.

- 10000000 respiration
- 01000000 C1
- 00100000 aVF
- 00010000 aVL
- 00001000 aVR
- 00000100 III
- 00000010 II
- 00000001 I

Example: to receive I, aVR and respiration, send: 0x43 (character ‚C‘), 0x89

Filtering of the waveforms for 50 and 60 Hz line frequency:

- „5“ Parameter: "0", "1" or "2" (0x35 0x30 for example for „50“)
- „0“ 50Hz and 60Hz Filter off
- „1“ 50Hz Filter on
- „2“ 60 Hz Filter on

Filtering of the waveforms for EMG interference (~15-30Hz):

- „E“ Parameter: „0“ or „1“ (0x45 0x30 for example for „E0“)  
 „0“ EMG Filter off (reset value)  
 „1“ EMG Filter on

Calibraton mode (1mV rectangle transmitted for 250 samples):

- „K“ output 250 samples of 1mV rectangular waves, then go back to normal mode

Update Electrode configuration. Recognizes newly connected electrodes

- „q0“ Newly connected electrodes are recognized after this command has been sent to the module. Also any other command except "K" and "I" starts a new search for connected electrodes.

Simulated data outputs (useful for testing or exhibitions):

- „M“ Parameter: „0“, or „1“  
 „0“ use real input for data transmission (reset value)  
 „1“ use simulated output waves and values

Pacemaker detection on or off:

- „P“ Parameter: „0“, or „1“  
 „0“ do not detect pacemaker pulses  
 „1“ detect pacemaker pulses (reset value)

Set delay of the pulse trigger signal (active high, 33ms duration):

- „T“ Parameter: „0“, „1“, „2“, or „9“  
 „0“ Delay of the pulse trigger signal 15ms (reset value)  
 „1“ Delay of the pulse trigger signal 50ms  
 „2“ Delay of the pulse trigger signal 100ms  
 „9“ The signal triggers in the middle between R waves

Identification of the module:

- „I“ Identify. A zero terminated ASCII string is transmitted showing module information. The identification block start with marker 0xFD.

## Test Program

A Microsoft Windows program (Monitor.exe) is available upon request. The program does not need any installation, just copy it to a directory of your choice and run it.

The software allows selection of transmitted channels, sample rate and amplification as well as selecting filters.

It graphically displays the selected channels.

## Regulatory considerations:

The device that has been described in this document is not a final medical product. That means that it cannot be used as a standalone unit to use it on patients.

Therefore, the EG05000 has not been - and also cannot be - CE-marked. The customer has to undertake the procedure of CE-marking with the final product that contains the module. However, several products on the market have successfully passed this certification.

The module complies with the following standards, as far as applicable:

IEC60601-1

IEC60601-1-2

IEC60601-1-4

IEC60601-2-27:2005

ANSI/AAMI EC13:2002

ANSI/AAMI EC57:1998

During testing and certification of a product, also the user manual of the final product needs to be certified. The user manual has to contain certain technical data and warnings to the end users. We can support customers by supplying material for the manual that has been used during the certification process of Medlab's devices.

## History:

Rev. 0.9:	Initial Revision
Rev. 0.91:	Adjusted Layout, Corrected typographical errors Moved "physical units" to begin of document Changed table of contents
Rev. 0.92:	Corrected Connector JP1 Layout Added two status messages Corrected packet markers 0xFa 0xF9 Added description of cable selection / electrode detection (page 11)
Rev. 1.00:	Added technical data required for testing against IEC60601-2-27
Rev. 1.01:	Added brief description of the test program Removed reference to EG01010 and protocol switching on power up Exchanged the word "packet" with "block" Corrected grammatical errors Added outputs to technical data page
Rev. 1.02:	Corrected JP1 description. Added Marker description for "Identify" block Corrected description of EKGStat byte in status block
Rev. 1.03:	Added JP1 "pulse trigger" and "shutdown pin" clarification Packet markers 0xFA and 0xF9 are exchanged again Changed company address
Rev. 1.04:	Added command description: Fx, Px, Tx

Medlab GmbH  
Erzbergerstrasse 115  
76133 Karlsruhe  
Germany  
Tel ++49 (0) 721 62512 0  
Fax ++49 (0) 721 62512 66  
oemsales@medlab-gmbh.de  
www.medlab-gmbh.de